
IMPORTANT NOTICE: HARDWARE PACKAGE IS ATTACHED ON THE BOTTOM OF SEAT CUSHION.

MODEL: B6338

(1)x1		(2)x1	(3)x1 (L)x1 (R)
Back Cushion		Seat Cushion W/Mechanism	Right & Left Arm
(4)x5		(5)x1	(6)x1
Casters		Gas Lift W/ Cover	Base
(A)x2 =	(These screws are		ACKET SCREW re in the adjustable arm
(B)x3		bracket attached to seat bottom) M8*22 L-BAR SCREW	
(C)x1 //		ALLEN KEY	J



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.



